


If spikt A.C., Fan direction controlled by step motorthrough socket 'MOTOR'.

3 phase compressor connect



L=U,V or W